

# MODULHARD'ANDREA

Balancing rings


Auswuchtringe

Anillos de equilibrado

Bagues d'équilibrage

Anelli di bilanciatura

**BLC**



REF.	CODE	MHD'	de	di (G <sub>6</sub> )	L
BLC 42.32	38 17 25 032 001	32	42	31.5	14
BLC 50.40	38 17 25 040 001	40	50	39.5	15
BLC 63.50	38 17 25 050 001	50	63.5	49.8	16
BLC 80.63	38 17 25 063 001	63	80	62.8	18

## ASSEMBLY

- Remove the plastic guard ring
- Insert the BLC ring and lock the A screws.

## MONTAGE

- Schutzring aus Kunststoff entfernen.
- Auswuchtring BLC einsetzen und Schrauben A spannen.

## MONTAJE

- Quitar el anillo de protección en plástico
- Insertar anillo BLC y fijar los tornillos A.

## MONTAGE

- Enlever la bague de protection en plastique
- Insérer la bague BLC et bloquer les clefs A.

## MONTAGGIO

- Togliere l'anello di protezione in plastica
- Inserire l'anello BLC e bloccare le viti A.

