





A/S .. SCLCR/L


 $\varnothing 8-16$


НАБОР ACL 8026 R/L 06

НАБОР SCL 8026 R/L 06



№ 1 A0608H SCLCR/L 06
№ 1 A1012K SCLCR/L 06
№ 1 A0810J SCLCR/L 06
№ 1 A1012M SCLCR/L 06



№ 1 S0608H SCLCR/L 06
№ 1 S1012K SCLCR/L 06
№ 1 S0810J SCLCR/L 06
№ 1 S1012M SCLCR/L 06

Обозначение	R	L	Dmin, мм	d, мм	f, мм	B, мм	L1, мм	
Без отверстия для подачи СОЖ								
S08K SCLCR/L 06	4	3	10	8	6	-	125	0602
S10K SCLCR/L 06	6	6	12	10	7	-	125	0602
S12M SCLCR/L 06	2	-	16	12	9	-	150	0602
S12M SCLCR/L 09	4	5	16	12	9	-	150	09T3
S16R SCLCR/L 09	5	2	20	16	11	-	200	09T3
S20S SCLCR/L 09	5	2	25	20	13	-	250	09T3
S25T SCLCR/L 09	2	2	32	25	17	-	300	09T3