



Обозначение	R	L	h=h1, мм	b, мм	f, мм	l1, мм	
PCLNR/L 16 16 H12	2	-	16	16	20	100	1204
PCLNR/L 2020 K 12	21	10	20	20	25	125	1204
PCLNR/L 2525 M 12	35	21	25	25	32	150	1204
PCLNR/L 3225 P 12	5	2	32	25	32	170	1204
PCLNR/L 2525 M 16	2	-	25	25	32	150	1606
PCLNR/L 3232 P 16	2	2	32	32	40	170	1606
PCLNR/L 3232 P 19	4	2	32	32	40	170	1906