



Обозначение	R	L	h=h1, мм	b, мм	f, мм	l1, мм	
PSSNR/L 2020 K 12	8	5	20	20	25	125	1204
PSSNR/L 2525 M 12	1	15	25	25	32	150	1204
PSSNR/L 2525 M 15	2	-	25	25	32	150	1506
PSSNR/L 3232 P 15	2	-	32	32	40	170	1506
PSSNR/L 3232 P 19	5	5	32	32	40	170	1906