



Обозначение	R	L	h=h1, мм	b, мм	f, мм	l1, мм	
SVJBR/L 1616 H 16	2	-	16	16	24	100	1604
SVJBR/L 2020 K 16	3	2	20	20	25	125	1604
SVJBR/L 2525 M 16	6	2	25	25	32	150	1604
SVJBR/L 3225 P 16	-	2	32	25	32	170	1604